



1/18




FIG. 1

2/18




FIG. 2

3/18




FIG. 3

4/18




FIG. 4

5/18




FIG. 5

6/18




FIG. 6A




FIG. 6B

7/18




FIG. 7

BASIC STEPS TO IDENTIFY AND PROGRAM THE MODULES

- LOADS ALL — 800
- THE APPLICATION SOFTWARE LIGHTS A PANEL ONE AT A TIME — 805
- THE USER THEN IDENTIFIES WHERE THE PANEL IS SITUATED WITHIN ALL PANELS CONNECTED. — 810
- THE APPLICATION SOFTWARE THEN RECORDS THE PANEL IDENTIFIER AND ITS LOCATION. — 815
- ONCE ALL PANELS HAVE BEEN IDENTIFIED AND POSITION CODED, THE INSTALLATION IS COMPLETE.

LATER VERSIONS OF THE PANELS WILL ELIMINATE THE USERS PARTICIPATION WHEN INSTALLING AND CONFIGURING A SYSTEM, THIS IS ACCOMPLISHED BY EACH PANEL HAVING A UNIQUE VOLTAGE ASSOCIATED WITH IT WHEN PANELS ARE INTERLOCKED.

FIG. 8

8/18




FIG. 9

9/18




FIG. 10




FIG. 11

10/18




FIG. 11A




FIG. 11B




FIG. 11C

11/18





FIG. 12

12/18



13/18




FIG. 14

SUGGESTED POSITIONS OF THE POWER FRAME ATTACHMENTS




FIG. 15

14/18




FIG. 16

15/18




FIG. 17A

16/18




FIG. 17B

17/18

· *INTERLOCK 8 OR MORE LCD MODBLOCK PANELS.*




FIG. 18A

· *DOWNLOAD SELECTED IMAGE FROM VISTOYS INTERNET SITE.*




FIG. 18B

18/18

- *DISASSEMBLE PANELS. THE DOWNLOADED IMAGE IS STILL PRESENT WITH NO POWER ATTACHED.*





FIG. 18C

- *ASSEMBLE THE SELECTED PIECES TRYING TO FORM THE DOWNLOADED IMAGE.*



- *WHEN ASSEMBLED CORRECTLY, THE IMAGE ANIMATES CONFIRMING CORRECT POSITIONING OF ALL PIECES.*

FIG. 18B